

Installation Instructions

1. Thoroughly clean the vacuum-head with a non-oil-based cleaning solution. Clean again with the provided alcohol wipes.

Note: Dirt will prevent Velcro® adhesive from adhering well.

2. Peel plastic backing from Velcro® and attach strips directly to the hard plastic frame of the vacuum-head as shown in Figures 1 and 2.

Note: Do not attach Velcro® to manufacturer's vinyl bumper.

3. Install VacuBumper™ 24-hours after attaching Velcro®.

Note: Adhesive reaches maximum strength 24-hours after Velcro® installation.

4. Center, stretch and attach the bumper as shown in Figures 3 through 5.
 - a. Bumper must completely cover the Velcro® to prevent dirt from attaching to adhesive.
 - b. Bumper must not hang below the vacuum-head, as this will impede the vacuum's performance.
 - c. Do not cover vacuum ventilation system.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

Care Instructions

Remove dust and debris with a lint-roller, or machine wash and line dry.

VacuBumper.com ~ Service@VacuBumper.com ~ (480) 699-1172
10645 N. Tatum Blvd., Suite 200-377, Phoenix, AZ 85028