



## Installation Instructions

1. Thoroughly clean the vacuum-head with a non-oil-base cleaning solution.  
**Note:** Dirt will prevent Velcro® adhesive from adhering well.
2. Peel plastic backing from Velcro and attach strips directly to the hard plastic frame of the vacuum-head as shown in Figure 1.  
**Note:** Do not attach Velcro to vacuum manufacturer's vinyl bumper.
3. For best results, install VacuBumper 24-hours after attaching Velcro.  
**Note:** Adhesive reaches maximum strength 24-hours after Velcro installation.
4. Center, stretch and attach the bumper as shown in Figures 2 through 4.
  - a. Bumper must completely cover the Velcro to prevent dirt from attaching to adhesive.
  - b. Bumper must not hang below the vacuum-head, as this will impede the vacuum's performance.
  - c. Do not cover vacuum's ventilation system.

## Care Instructions

Remove dust and debris with a vacuum attachment or lint-roller.  
Machine washable; air dry.

Figure 1



Figure 2



Figure 3



Figure 4

